

KADO

**Kado Neue Freestanding Bath
1730 x 780 x 730mm White****INSTALLATION INSTRUCTIONS:**

NOTE: Please check the surface thoroughly before installing. Installation of bath will be taken as acceptance of the product.

It is important to install the product in accordance with the installation instructions below.

This installation guide does not include details of waste connection. Final decision about the installation of the waste connection should be taken by a suitably qualified person in accordance with the plumbing code AS/NZS 3500.

1. Install the waste wipe and trap taking into consideration the waste position of the bath
2. Make sure that the surface where the bathtub will be placed is perfectly flat, clean, free of any excess humidity and offers adequate support
3. For installation where access is restricted eg: a slab floor or second story floor, the use of a Plumbdinger (Product Code: 1409790) waste connection is recommended (for installation refer to Plumbdinger instructions)
4. Fit selected waste to bath and ensure waste is siliconed around the base
5. Inspect thoroughly for leaks

CLEANING RECOMMENDATIONS:

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions