

KADO

**Kado Neue Freestanding Bath
1730 x 780 x 730mm Matte White/Matte Black****INSTALLATION INSTRUCTIONS:**

NOTE: Please check the surface thoroughly before installing. Installation of bath will be taken as acceptance of the product.

It is important to install the product in accordance with the installation instructions below.

This installation guide does not include details of waste connection. Final decision about the installation of the waste connection should be taken by a suitably qualified person in accordance with the plumbing code AS/NZS 3500.

1. Install the waste wipe and trap taking into consideration the waste position of the bath
2. Make sure that the surface where the bathtub will be placed is perfectly flat, clean, free of any excess humidity and offers adequate support
3. For installation where access is restricted eg: a slab floor or second story floor, the use of a Plumbdinger (Product Code: 1409790) waste connection is recommended (for installation refer to Plumbdinger instructions)
4. Fit selected waste to bath and ensure waste is siliconed around the base
5. Inspect thoroughly for leaks

CLEANING RECOMMENDATIONS:

If the matte white surface of the bath appears to be scratched or dirty, the matte surface CANNOT be polished. It will lose its matte finish and become glossy. A grenadine sanding block will be included with the bath to lightly buff out the scratches or remove dirt.

If the matte black surface of the bath appears to be scratched or dirty, the matte surface should be lightly polished. Do not attempt to clean or buff out any scratches with harsh sponges or sanding blocks. It will lose its matte finish and potentially remove the black colour.

We recommend the use of soapy water. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions

Plumbers, please ensure a copy of the Installation Instructions are left with the end user for future reference