

# Posh

## Posh Domaine Back to Wall Freestanding Bath 1500 x 720mm White

### INSTALLATION INSTRUCTIONS:

1. Install waste pipe and trap - taking into consideration the waste position of the bath. Make sure that the surface where the bathtub will be placed is perfectly flat, clean, free of any excess humidity and offers adequate support.
2. The bath should be supported by the legs, not by the rim. Adjust the feet to level and support bath from base. (Adjustment range up to 50mm)
3. For installation where access is restricted eg slab floor, or second story floor, the use of a Plumbdinger (product code 1409790) waste connector is recommended (for installation refer to Plumbdinger instructions).
4. Fit selected waste to bath and ensure waste is siliconed around rim.
5. Inspect thoroughly for leaks.

### NOTE:

Please check the surface thoroughly before installing. Installation of bath will be taken as acceptance of product. It is important to install the product in accordance with the installation instructions below.

This installation guide does not include details of waste connection; final decision about the installation of waste connection should be taken by a suitably qualified person in accordance with the plumbing code AS/NZS 3500.

### CLEANING RECOMMENDATIONS:

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions